




PREPARE THE GROUND, UNWRAP THE PACKAGE,
LAY OUT THE COMPONENTS, FIND THE TOOLS.

GNESTA 40



4x40 × 120

4x50 × 850



5x70 × 15

6x140 × 70



M8x70 × 16

1,4X40 × 30

LAY OUT THE FOUNDATION BEAMS AND SQUARE IT BY MEASURING FROM CORNER TO CORNER.



GNESTA 40





MAKE SURE THAT THE FOUNDATION IS INSTALLED ON A LEVEL SURFACE. CHECKING ALL DIRECTIONS, INCLUDING CORNER TO CORNER. 3%

LAY OUT THE FOUNDATION BEAMS AND SQUARE IT BY MEASURING FROM CORNER TO CORNER.





6x140
× 18

GNESTA 40






LAY OUT THE **BOTTOM** LOGS,
ATTACH TO THE FOUNDATION.

GNESTA 40




THE WALL **LOGS** WILL HANG OVER
THE FOUNDATION **BEAMS** BY
APPROXIMATELY 5MM. THIS OVERHANG
IS DESIGNED AS A RAIN DRIP. **5%**

ATTACH THE FIRST ROW OF
WALL LOGS INTO THE BOTTOM
LOGS WITH **SCREWS**.





AFTER PLACING 3-4 ROWS OF WALL LOGS, TAP EACH WALL LOG IN PLACE USING A HAMMER AND THE HITBLOCK PROVIDED, TO TIGHTEN THE LOGS.

GNESTA 40




SLIDE THE DOOR IN,
ATTACH THE HANDLE.

GNESTA 40




DON`T FORGET TO
TIGHTEN THE LOGS AFTER
EVERY 3-4 ROWS.

GNESTA 40



SLIDE THE WINDOW IN,
ATTACH THE HANDLE.

GNESTA 40






INSTALL THE GABLES WITH LONG SCREWS TO THE WALL LOGS ON THE FRONT AND REAR WALLS.

GNESTA 40

6x140 × 8



Ø 5 mm




INSTALL THE ROOF PURLINS AND ROOF ELEMENTS 1, ATTACH THEM WITH SCREWS.

6x140 × 10

Ø 5 mm





GNESTA 40



PLACE THE FIRST **ROOFBOARD** FLUSH WITH THE END OF THE **PURLINS** AND ATTACH WITH **SCREWS**. SAW THE LAST **BOARD** TO MAKE IT FIT.

GNESTA 40


4x50
× 475



FOR THE FASCIA TRIMS INSERT
SCREWS AFTER EVERY 0,5 METERS.

GNESTA 40


4x40
× 44



EAVES EDGES GO ON TOP OF THE ROOFING*.
*(NOT INCLUDED).

GNESTA 40



4x40 × 52
Ø 3 mm



ATTACH ROMBS WITH SCREWS.

GNESTA 40


4x40
× 4
Ø 3 mm



18 SCREWS INTO THE FIRST FLOORBOARD,
9 INTO EACH NEXT, SAW THE
LAST BOARD TO MAKE IT FIT.

4x50 × 297


Ø 3 mm





GNESTA 40

SAW THE **BASEBOARDS**
AND ATTACH WITH NAILS
AT **EVERY 0,5** METERS.

1,4X40
× 30



GNESTA 40




BB


DRILL THROUGH THE WALL, HOLE MUST BE AT THE BOTTOM OF THE OVAL, ATTACH WITH BOLT.

M8x70 × 16

Ø 8 mm






GNESTA 40



WINDBOARD


IF DOOR IS TILTED,
PUSH THE DOOR FRAME SO
THAT ALL CORNERS ARE 90°.

GNESTA 40



IF **DOORS** ARE IN DIFFERENT HEIGHTS
OR THERE IS A GAP **BETWEEN** THEM,
ADJUST 3 SCREWS ON DOOR HINGES.

GNESTA 40



WHEN THE **HOUSE** IS ASSEMBLED, YOU SHOULD **COVER** THE TIMBER WITH **WOOD** PROTECTIVE SEAL, PAINT OR **STAIN** AS SOON AS POSSIBLE TO AVOID DETERIORATION TO THE **WOOD**.

GNESTA 40

